DARIORASERO

Zeroll® and Zerolon® ice cream scoops and Zeroll® Spade

Instructions for use, safety, cleaning and maintenance · all sizes

Importer for Italy: Euro Satip Srl, Via Nicomede Bianchi 109, 10146 Torino · info@dariorasero.com · +39 011 74 92 922



READ BEFORE USE

Read these instructions before use and keep them for the whole life of the product. The «General warnings and conditions of use» (dariorasero.com) are also part of these instructions.

1. INTENDED USE

Scoops: portioning ice cream, sorbets and cold preparations. Spade: levelling and filling ice cream pans. The aluminium handle contains a **sealed heat-conductive fluid** that transfers heat from the hand. Zerolon®: with non-stick coating.

NOTE – WASHING

Do not wash in a dishwasher, do not immerse in water above 60 °C, do not heat-sterilise: heat damages the fluid and alkaline detergents attack aluminium.

PROHIBITED USE

Do not use as a lever or chisel on hardened ice cream or ice; do not knock it on the edge of the pan; do not pierce or bend the handle; do not use it for cooking or with hot food.

2. USE

1. Hold the handle close to the bowl.
2. Draw the scoop across the surface of the ice cream, towards you, slightly tilted.
3. Turn your wrist, lift the portion and release it. The cap colour indicates the size; the portion depends on the ice cream and is not a legal measure.

3. CLEANING

By hand only, with lukewarm water (never above 60 °C) and neutral detergent, using a soft sponge; dry immediately. In the dipper well between portions, use running water at room temperature or lukewarm. Do not use alkaline detergents, chlorine, acids, scouring pads or abrasives; on the Zerolon® coating, no abrasive sponges or metal utensils.

4. INSPECTION, STORAGE AND DISPOSAL

If the handle is pierced, deformed or leaking fluid, do not use the product and discard any ice cream that has come into contact with the fluid: the product cannot be repaired. Also replace it if the bowl or blade is deformed, the aluminium is corroded, the coating is damaged or the coloured cap is missing. Store dry. At end of life: metal recycling, without piercing the handle.

5. FOOD CONTACT

Parts in contact with food: the **bowl** of the scoops and the **blade** of the spade; on Zerolon®, the non-stick coating. The declaration of compliance is sent with the shipping confirmation.

INSTRUCTIONS FOR ALUMINIUM ARTICLES

- Not suitable for contact with strongly acidic or strongly salted foods.
- Intended for contact with food at refrigerated temperatures.
- Intended for contact with food at non-refrigerated temperatures for periods not exceeding 24 hours.
- Intended for contact at room temperature, also for periods exceeding 24 hours, with the following foods: cocoa and chocolate products; coffee; spices and herbs for infusion; sugar; cereals and cereal products; non-fresh pasta; bakery products; dried pulses and pulse products; dried fruit and nuts; dried mushrooms; dried vegetables; confectionery products; fine bakery wares, provided that the filling is not in direct contact with the aluminium.

Warranty, liability, obligations of professional users, traceability and reporting: see the «General warnings and conditions of use» published on dariorasero.com. In case of discrepancy between the language versions, the Italian version prevails.